

****If the machine does not start with this display...**

RESET MACHINE

CREDIT.....SALE ACCOUNT OFFLINE
--

(The word “Offline” should be blinking.), you need to reset it to offline mode.

To Reset the Machine to Offline Mode:

1. Press the yellow “**menu**” key.
2. Press “**3**”.
3. Press the “**forced**” key (above green “enter” key) until **option 10: “Store & Forward”**. Press the green “**enter**” key.
4. Enter the **password**. The password is **today’s date** in MMDDYYYY format. Example: 03152008 (mar. 15, 2008). Press the green “**enter**” key.
5. Press the “**forced**” key until **option 2: “Mode Select”**. Press the green “**enter**” key.
6. Press the “**forced**” key until **option 2: “Stay Offline”**. Press “**enter**” key.
7. Press the yellow “**menu**” key.
8. Press “**enter**” key thru all the prompts about limits (might be 2 prompts). **You are watching for the screen to ask “offline anyway?”** When you see that prompt, press “**enter**” key.
9. Printer will print “Store and Forward Mode”, remove and throw away.
10. Finally, press “**menu**” key 3 times until screen returns to:

CREDIT.....SALE ACCOUNT OFFLINE
--

You are now ready to start processing credit cards. See the instructions on the previous page.

Need Help? Call us @ 781-935-3339